# netstar

Smart Full Touch Switch Panel

User Manual

Installation Instructions:

1. Cut-off the power before Installation for Safety.
2. Use of Neutral wire is mandatory for Connection.
3. Set WiFi Router at 2.4 GHz Frequency.
4. Please check the wiring diagrams given in this user manual and connect the wires accordingly.
5. Install the Touch Switch Panel on the Box. if it is not fitting, please double check if the correct sized item has been ordered according to the Box. Please contact our support team for further help.
6. Turn on the power supply and follow next section instructions for App Configuration. (For WiFi enabled Switches)

App Configuration:

1. Download Netstar App in your smart phone and complete the one-time registration.
2. Make sure Mobile Bluetooth and Location is Turned On & connected to your Wi-Fi network (2.4Ghz Frequency).
3. Check if switch Blue LED light is blinking (= switch is in configuration mode)

4. Smart Touch panel: If LED is not blinking, then please Touch first switch (On Top Left Side) for 15 to 20 seconds continuously till the LED starts blinking.

5. Open the App, select "+" button on the top right corner to Add Device.
6. You can either use Auto Scan option to select the switch automatically OR to Add switch manually, Go to Electrical section, Scroll down to Switch and select Switch (BLE+Wi-Fi).
7. App will prompt for Wi-Fi ID and Password. Please enter the same.
8. Please wait till the App completes configuration – Blue LED should stop blinking within 20-180 seconds - means the Linkage is completed.
9. You can rename the added switch as per your wish.
10. Click "Done" to complete the configuration. You can now the operate the smart Switch using Netstar App.

Alexa Set-up:

1. Download & Register Amazon Alexa app in your phone.
2. Select Skills & Games, search and link with "NETSTAR Home".
3. After Successful linking, ask "Alexa discover my devices" and Alexa will show all discovered devices.
4. This complete the Alexa linkage. If any device was not discovered, please check internet connection and repeat the process as stated above.

Google Set-up:

1. Download Google Home app in your mobile & Register.
2. Open the App, select "+" button on the top left corner to "set up device" and select "works with Google".
3. Search and select "NETSTAR Home", it will link your switches automatically.
4. This complete the Google Home linkage. If any device was not discovered, please check internet connection and repeat the process as stated above.

2 Switch

HV | L | NO COM NC | L | N

High Voltage(16A)

Normally Open
Common/Load
Normally Close

Neutral
Line
(Phase)

4 Switch 1 Fan

HV | L | NO COM NC | F | L2 L1 | L | N

Load 4(16A)

Load 3

No use
Load 2
Load 1

Fan

Neutral
Line(Phase)

8 Switch

THIS TWO (L) ARE internally connected

L6 HV L L | NO COM NC | L4 L3 | | L5 L2 L T L | N

LOAD6 HV(16A)

LOAD4 LOAD3

LOAD5 LOAD2 LOAD1

Normally close
Common/Load
Normally Open

NEUTRAL

LINE

2 Switch (2-2way)

NO COM NC | NO COM NC | L | N

Normally Open
Common/Load 2
Normally Close
Normally Open
Common/Load 1
Normally Close

Neutral
Line(Phase)

6 Switch 1 Fan

HV L | NO COM NC | F | L4 L3 L2 L1 | L | N

Load 6
(16A)
Load 5

No use
Fan
Load 4
Load 3
Load 2
Load 1

Neutral
Line(Phase)

Curtain

NO COM NC | NO COM NC | L | N

Close

No use
Open

No use

Neutral
Line
(Phase)

netstar

MAKE IN INDIA